

# CUSTOM SHAPE

CUSTOMER TAG NAME:

ORDER INFORMATION

QUOTE #: \_\_\_\_\_ SQ#: \_\_\_\_\_

PO#:


## FIBERGLASS STEPS

YES -->  STRAIGHT  RADIUS \_\_\_\_\_  
 LOCATION  CENTER SHALLOW END  OTHER (DRAW IN LOCATION)

## VINYL COVERED STEPS

YES --> NOTE: STEP MEASURING FORM REQUIRED  
 LOCATION:  CENTER SHALLOW END  OTHER (DRAW IN LOCATION)

## DEPTH MEASUREMENTS



## HOPPER PAD CORNERS


SQUARE  
 RADIUS \_\_\_\_\_ IN.

## CORNER SIZE & SHAPE

SQUARE

RADIUS

DIAGONAL



## POOL DRAWING

IMPORTANT! INCLUDE AB LINE IN YOUR SKETCH BELOW.

DISTANCE OF POINT A TO POINT B: \_\_\_\_\_  
 PROVIDE A - B FORM.

# CUSTOM SHAPE MEASURING FORM

ORDER INFORMATION	
QUOTE#:	PO#:
SO#:	

CUSTOMER TAG NAME:

## AB POINTS

A		B		A		B		A		B	
FT	IN	FT	IN	FT	IN	FT	IN	FT	IN	FT	IN
1				31				61			
2				32				62			
3				33				63			
4				34				64			
5				35				65			
6				36				66			
7				37				67			
8				38				68			
9				39				69			
10				40				70			
11				41				71			
12				42				72			
13				43				73			
14				44				74			
15				45				75			
16				46				76			
17				47				77			
18				48				78			
19				49				79			
20				50				80			
21				51				81			
22				52				82			
23				53				83			
24				54				84			
25				55				85			
26				56				86			
27				57				87			
28				58				88			
29				59				89			
30				60				90			

## SHALLOW BREAK POINTS

PT # \_\_\_ TO PT # \_\_\_

## DEEP BREAK POINTS

PT # \_\_\_ TO PT # \_\_\_

## FIBERGLASS STEP

PT # \_\_\_ TO PT # \_\_\_

STRAIGHT  RADIUS

## VINYL COVERED STEP

PT # \_\_\_ TO PT # \_\_\_


Note: Provide correct step measuring form.

## TRANSITION SLOPE MEASUREMENTS

MEASURE PERPENDICULAR TO SIDE WALL

*SEE DIAGRAM 1 BELOW	DISTANCE OUT
PT # _____	_____ IN.
PT # _____	_____ IN.
PT # _____	_____ IN.
PT # _____	_____ IN.

DIAGRAM 1



	FT	IN
DISTANCE FROM "A" TO "B"		

FT IN

	FT	IN	From PT #	TO PT #
Overall Length				
Overall Width				
Optional 2nd Overall Length				
Optional 2nd Overall Width				

COMMENTS / SPECIAL NOTES:

